



PREMIUM  
**PRO-TEX™**  
TRUCKBED LINER

# UNSTOPPABLE PROTECTION FOR A RUGGED LIFESTYLE

- Won't chip, crack, fade, or peel
- Heavy duty 18 mil thickness
- 6 qt kit for full size beds without sacrificing coverage
- Resistant to solvents, gas, oil, salt water, ammonia & more
- Easily tintable to OEM colors including white



BLACK KIT



TINTABLE KIT

AUTOMOTIVE | AGRICULTURAL | COMMERCIAL | INDUSTRIAL | MARINE | RECREATIONAL | RESIDENTIAL



# INSTRUCTIONS

For full details, refer to the Technical Data Sheet.

## STEP 1 PREP

Pressure wash and allow to dry.

Clean with **SEM Solve** or **Zero VOC Surface Cleaner**.

Wipe clean in one direction with dry, lint-free cloth.



### SEM Solve

A virgin solvent blend to clean panels prior to refinish or repair.

Part	Size
38371	Gallon
38373	20 oz. Aerosol
38374	Square Quart



### XXX Universal Surface Cleaner

A water based cleaner designed to eliminate surface contaminants prior to refinishing.

Part	Size
77771	Gallon
77774	Quart

## STEP 2 SAND & PRIME

Truckbed liners may be sprayed over OEM finishes. Remove all rust and prime any bare metal areas. Sand inside of bed with P180 – P220 grit or bed brush.

Apply a two-component epoxy primer, such as **World Class DTM Primer** or **Metalock DTM High Build Primer**, or apply a two-component direct-to-metal urethane primer over any bare metal following the manufacturer's instructions.

Sand the primer with P180 – 220 grit paper. Blow off dust and tack clean.



### World Class™ DTM Primer

A 2.1 VOC compliant, two-component epoxy that provides bare metal adhesion and filling in one product.

Part	Size
50121	Gallon
50124	Quart



### Metalock™ DTM High Build Primer

A two-component, epoxy primer for use on steel, aluminum, SMC and fiberglass.

Part	Size
ML014	Quart
ML010	1.25 Gallon Kit

## STEP 3 APPLY

Refer to the **Technical Data Sheet** for mixing instructions.

Spray 2 – 3 light coats. Allow 15 – 20 minutes at 70° F between coats. The first coat should not achieve full coverage and subsequent coats should be applied in the same manner. Remove masking tape immediately after applying final coat.



Part	Size
40640	Black Kit
40660	Tintable Kit



### Pro-Tex

A professional, two component, urethane liner system that provides a hard, durable finish and superior protection to truckbeds, equipment, and various other surfaces.



**SEM Products, Inc.**  
Rock Hill, SC 29730  
1-800-831-1122  
semproducts.com



Learn about  
**Pro-Tex Premium Truckbed Liners**  
[semproducts.com/pro-tex](http://semproducts.com/pro-tex)