

# SURE-COAT™

## WATERBORNE



## CHANGE OR ENHANCE THE COLOR OF LEATHER, VINYL OR PLASTIC

- OEM recommended
- Will not soften or crack
- Thousands of formulas including many OEM matched colors
- Easy to use
- VOC compliant
- Will not peel
- Excellent coverage



## STEP 1 PREP

Clean first with **SEM Soap** and a gray scuff pad. Rinse with water or wipe soap residue with a clean damp cloth.

For vinyl, clean with **Vinyl Prep** and remove with damp towel.

For plastic and vat-dyed or PVC coated leather, clean with **Plastic & Leather Prep**.

Scuff leather with a clean, gray scuff pad or 400 – 600 grit sandpaper and clean again with **Plastic & Leather Prep**.



### SEM Soap

A mild abrasive cleaner for flexible substrates.

Part	Size
39362	16 oz. Tube



### Vinyl Prep

A strong solvent blend for refinishing vinyl.

Part	Size
38343	16 oz. Aerosol
38344	Quart



### Plastic & Leather Prep

A mild solvent blend to clean plastic and leather.

Part	Size
38351	Square Gallon
38353	16 oz. Aerosol
38354	Cone Top Quart

## STEP 2 MIXING

**Sure-Coat** is ready to spray. Hand stir or shake well to make sure color is consistent.

It may appear foamy; however, bubbles will dissipate during application.

You can also use **Sure-Coat Flattener** to decrease the gloss of **Sure-Coat** colors.



### Sure-Coat Cross Linker

Increases durability against most cleaning chemicals.

Part	Size
16004	4 oz.



### Sure-Coat Reducer

Helps with specialty applications and blending.

Part	Size
16754	Quart



### Sure-Coat Flattener

Helps match low gloss OEM colors.

Part	Size
16808	Pint

## STEP 3 APPLY

**SPRAY:** Always flush gun with acetone followed by deionized water prior to application. Hold 6 – 8 inches from the surface. Using fluid tip size 1.3 – 1.4 at 25 – 30 psi from non-HVLP equipment or 8 – 10 psi at the cap with HVLP equipment, apply one light coat followed by two medium wet coats allowing 5 – 10 minutes flash time between coats. Apply sufficient coats to achieve hiding.

**BRUSH:** Use a **05500 Poly-Brush Applicator** and apply one light coat followed by two medium wet coats allowing 5 – 10 minutes flash time between coats. You can also use the **Custom Fill Waterborne Aerosol Blank** or **70400 Sure-Coat Dauber Bottle**. Apply sufficient coats to achieve hiding.



### Custom Fill™ Waterborne Aerosol Blank

Fill with Sure-Coat for convenient high quality repairs.

Part	Size
62003	16 oz. Aerosol

**Sure-Coat** Also available in 1/2 gallon

Part	Size	Color	Part	Size	Color
16018	Pint	Black	16568	Pint	Thalo Green
16088	Pint	Silver	16578	Pint	Magenta
16508	Pint	Red Oxide	16588	Pint	Bright Red
16518	Pint	Indo Yellow	16598	Pint	Yellow Oxide
16528	Pint	Quindo Red	16708	Pint	High Gloss Clear
16538	Pint	Thalo Blue	16718	Pint	Satin Gloss Clear
16548	Pint	White	16728	Pint	Low Luster Clear



**SEM Products, Inc.**  
Rock Hill, SC 29730  
1-800-831-1122  
semproducts.com



Learn about Sure-Coat  
[semproducts.com/sure-coat](http://semproducts.com/sure-coat)